



# MODEL AUTOJIG

**84-72 MJ**

## PARTS AND SERVICE MANUAL

MACHINE SERIAL No:

**PART NUMBER 97.8472.1.000**





## LIMITED WARRANTY ON NEW AMF REECE EQUIPMENT

### Warranty provisions:

A ninety (90) day limited service labor warranty to correct defects in installation, workmanship, or material without charge for labor. This portion of the warranty applies to machines sold as "installed" only.

A one (1) year limited material warranty on major component parts to replace materials with defects. Any new part believed defective must be returned freight prepaid to AMF Reece, Inc. for inspection. If, upon inspection, the part or material is determined to be defective, AMF Reece, Inc. will replace it without charge to the customer for parts or material.

Service labor warranty period shall begin on the completed installation date. Material warranty shall begin on the date the equipment is shipped from AMF Reece, Inc.

### Exclusions:

Excluded from both service labor warranty and material warranty are: (1) Consumable parts which would be normally considered replaceable in day-to-day operations. These include parts such as needles, knives, loopers and spreaders. (2) Normal adjustment and routine maintenance. This is the sole responsibility of the customer. (3) Cleaning and lubrication of equipment. (4) Parts found to be altered, broken or damaged due to neglect or improper installation or application. (5) Damage caused by the use of non-Genuine AMF Reece parts. (6) Shipping or delivery charges.

There is no service labor warranty for machines sold as "uninstalled".

Equipment installed without the assistance of a certified technician (either an AMF Reece Employee, a Certified Contractor, or that of an Authorized Distributor) will have the limited material warranty only. Only the defective material will be covered. Any charges associated with the use of an AMF Reece Technician or that of a Distributor to replace the defective part will be the customer's responsibility.

NO OTHER WARRANTY, EXPRESS OR IMPLIED, AS TO DESCRIPTION, QUALITY, MERCHANTABILITY, and FITNESS FOR A PARTICULAR PURPOSE, OR ANY OTHER MATTER IS GIVEN BY SELLER OR SELLER'S AGENT IN CONNECTION HEREWITH. UNDER NO CIRCUMSTANCES SHALL SELLER OR SELLER'S AGENT BE LIABLE FOR LOSS OF PROFITS OR ANY OTHER DIRECT OR INDIRECT COSTS, EXPENSES, LOSSES OR DAMAGES ARISING OUT OF DEFECTS IN OR FAILURE OF THE EQUIPMENT OR ANY PART THEREOF.

## WHAT TO DO IF THERE IS A QUESTION REGARDING WARRANTY

If a machine is purchased through an authorized AMF Reece, Inc. distributor, warranty questions should be first directed to that distributor. However, the satisfaction and goodwill of our customers are of primary concern to AMF Reece, Inc. In the event that a warranty matter is not handled to your satisfaction, please contact AMF Reece office:

AMF Reece - Cars s.r.o.  
Tovární 837/9c  
798 11 Prostejov  
Czech Republic  
e-mail: [info@amfreece-cars.cz](mailto:info@amfreece-cars.cz)



## Service Manual

### Contents

- 1 Introduction
- 2 Using Jigs
- 3 Operating Instructions
- 4 Setting Procedures
- 5 Controller, Program Description  
and Electrical Circuit Diagram
- 6 Pneumatics
- 7 Head Setting Procedures
- 8 Synchroniser



# 1 - INTRODUCTION




## SAFETY INSTRUCTIONS

- The machine must only be used for the purpose it was designed for. In case of conversion into another version all valid safety instructions have to be considered.
- Do not operate this machine without the safety devices it is equipped with.



All guards must be in position before starting

- The machine must only be switched on and operated by persons who have been instructed accordingly.



Unauthorized Persons not to use this machine.

- When exchanging parts and when doing maintenance work the machine must be disconnected either by actuating the master switch or by removing the mains plug.



**CAUTION**  
Risk of electric shock

- When threading machine Emergency Stop must be engaged or the machine switched off.

CONTINUED.....

## 1 - INTRODUCTION

---



### SAFETY INSTRUCTIONS CONTINUED

- When carrying out maintenance or repair work on pneumatic devices the machine must be disconnected from the pneumatic supply source.



- Work on electrical equipment on this machine must only be carried out by electricians or other persons who have instructed accordingly.



- The actual 'A' weighted sound pressure level taken on an identical machine is 75.5 DB (A)
- Take appropriate measures for protection of hearing if sound pressure of 85 DB (A) is exceeded.



- Ensure lifting rail is used when lifting with fork lift truck.



# 1 - INTRODUCTION

---

## **IMPORTANT NOTES**

To avoid trouble or damage it is absolutely necessary to observe the following instructions.

- Before you put the machine into operation for the first time clean it thoroughly, remove all dust which has accumulated on it.
- Oil all necessary parts ensuring drive wheel section is free from any type of lubricant.
- Check to make sure line voltage agrees with the voltage indicated on the motor rating plate. If it does not, be sure not to plug in the machine.
- The balance wheel should always rotate towards you (when standing at the front of the machine). If it does not, alter the direction of the motor. Refer to Efka manual section, motor direction setup.
- Check you have the correct pneumatic line pressure.
- Always make sure the correct program is selected on the AMF Reece controller related to the type of jig being used.

## 1 - INTRODUCTION

---

### QUICK REFERENCE SPECIFICATION SHEET

|                     |   |
|---------------------|---|
| ELECTRICAL REQ:     | 220v @60Hz, single phase, 600W<br>240v @50Hz, single phase, 600W                |
| AIR SUPPLY:         | Pressure - 80 p.si (5.5 Bar)<br>Consumption - 0.40 c.f.m (12 l/Min)             |
| NOISE LEVEL:        | 75.5 DB (A)   |
| SEWING HEAD:        | Lockstitch with underbed trimmer  |
| SEWING HEAD MOTOR:  | <b>AB221A</b>   |
| SEWING HEAD SPEED:  | 2600 SPM (at max)   |
| STITCH SIZE:        | 0.5mm - 3.5mm (max varies with material)  |
| LUBRICATION SYSTEM: | Sump Reservoir, Wick and Pump<br>Distribution System, Jig Track - Silicon Spray |
| NEEDLE TYPE:        | <b>134 R</b>  |
| RECOMMENDED THREAD: | Core spun polyester/cotton.   |
| SEWING AREA:        | 175 x 175mm   |
| TABLE HEIGHT:       | 930mm (36.5")   |
| OPERATOR POSITION:  | Standing  |

## 2 - USING JIGS

### 2.1 Loading of Material into the Jig (e.g. Collar)

- a) Open jig and position lower ply of cloth to the jig location marks.
- b) If the jig has a fulling bar (i.e. middle section) close this on to the lower ply of cloth.
- c) Position the upper ply of cloth to jig location marks.
- d) Close the top plate of the jig.
- e) Jig now ready to insert into machine.

### 2.2 Loading jig to the machine

- a) Slide the loaded jig with the right hand on the top plate, towards the needle, lining up the start position approximately 1/2" (13mm) behind the needle.

**NOTE:**

When the jig is loaded, do not lift up from the table.

- b) Push the jig to the right and over the raised flap in front of the needle plate.
- c) As the jig is pushed to the right, the jig flap will drop to its normal position.
- d) If the jig is located correctly, the raised 'D' shape of the needle plate will locate in the track of the jig.
- e) Pull jig back to closed track. (Double jig should be pulled back so jig contacts presser foot).
- f) When the jig is loaded correctly to the machine, press the green start button located on the table top; and the automatic cycle will begin.
- g) At the end of the cycle the jig will be ejected (or, in the case of a double jig, wait to be pulled forward to its start position).

**NOTE:**

The machine has an A.M.F. Reece controller that is programmed to perform different functions, depending on the type of jig being used.

### 2.3 Program Selection

The different programs are achieved by selecting programs 1 – 6 on the A.M.F. Reece controller.

- a) Single pocket Flap - select program 1



- b) Double Pocket Flap - select program 2



- c) Collar Jig - requiring needle down both corners - select program 3



- d) Collar Jig - slow sew round collar - select program 4



- e) Single Breasted Jacket - select program 5



- f) Double Breasted Jacket - select program 6



### 3 - OPERATING INSTRUCTIONS

#### 3.1 To start up the Machine

- a) Turn the green switch on the right hand front panel of the machine, to switch on the air supply to the machine.
- b) Press black button on starter box.

**NOTE:**

The presser foot of the machine is always in the raised position when the machine is in the 'Stop' mode with the air and power switched on.



Carry out the following steps of procedure after the power switch has been turned OFF.

#### 3.2 Installation of Needle

Insert the needle to the needle bar to the full with its longer groove to the left, and firmly fasten by using the needle clamp screw (Figure 3.1).

Applicable needle: 134

**NOTE:**

Needle size and needle point are dependent on the type of material being used. (Refer to needle and thread section 3.13).

- a) Using a screwdriver, loosen the needle set screw on the left hand side of the needle bar.
- b) Insert the needle and push it up as far as it will go (make sure the long groove faces towards the left).
- c) Tighten needle set screw securely.




Figure 3.1

#### 3.3 Threading of Upper Thread

Turn the handwheel toward you to make the thread take-up reach the highest position, and run a thread from the spool pin to the needle through each part in such an order as numbered in Figure 3.2. At the needle, run the thread from left to right and leave the thread end for approx. 5 cm.




Figure 3.2

### 3 - OPERATING INSTRUCTIONS

#### 3.4 Bobbin winding

- a) Set the bobbin with the bobbin winder spindle, and wind the thread on the bobbin for a few turns by hand.
- b) Push fully the bobbin winder setting lever to make the winder pulley contact with the V-belt.
- c) Set winding capacity at 80% using the bobbin winding capacity regulating screw.
- d) If bobbin winding is uneven, adjust the position of the bobbin winder complete so that winding becomes even.
- e) When winding finishes, the bobbin winder setting lever flips up and the bobbin winding pulley stops.




Figure 3.3

#### 3.5 Bobbin setting into Bobbin Case

- a) Set the bobbin in the bobbin case in such a way that the bobbin will rotate in the direction as shown by arrow in Figure 3.4 when thread is pulled out.
- b) Run a thread through the thread guide of the bobbin case and draw the thread, and the thread will come out from the thread feeder through the tension spring.




Figure 3.4

### 3 - OPERATING INSTRUCTIONS

#### MACHINE ADJUSTMENTS

**3.5 Upper Thread Tension (Figure 3.5)**

Use the tension regulating thumb nut. Clockwise turns increase tension, and counterclockwise turns decrease tension.




Figure 3.5

**3.7 Lower Thread Tension (Figure 3.6)**

Turn the tension screw clockwise to increase, and counterclockwise to decrease.




Figure 3.6




Figure 3.7

### 3 - OPERATING INSTRUCTIONS

#### 3.8 Adjustment of Stitch Length

To adjust the stitch length, turn the feed regulating dial (Figure 3.8).




Figure 3.8

#### 3.9 Adjusting The Thread Take-up Stroke



Carry out the following steps of procedure after the power switch has been turned OFF.

- 1) When sewing heavy-weight materials, move thread guide ❶ to the left (in direction ❸) to increase the length of thread pulled out by the thread take-up.
- 2) When sewing light-weight materials, move thread guide ❶ to the right (in direction ❹) to decrease the length of thread pulled out by the thread take-up.
- 3) Normally, thread guide ❶ is positioned in a way that marker line ❷ is aligned with the center of the screw.




#### 3.10 Thread Take-up Spring

##### 1. Changing the stroke of thread take-up spring ❶

- 1) Loosen setscrew ❷.
- 2) As you turn tension post ❸ clockwise (in direction ❹), the stroke of the thread take-up spring will be increased.
- 3) As you turn the knob counterclockwise (in direction ❺), the stroke will be decreased.

##### 2. Changing the pressure of thread take-up spring ❶

- 1) Loosen setscrew ❷, and remove thread tension (asm.) ❸.
- 2) Loosen setscrew ❹.
- 3) As you turn tension post ❺ clockwise (in direction ❻), the pressure will be increased.
- 4) As you turn the post counterclockwise (in direction ❼), the pressure will be decreased.



#### Cleaning

Clean the hook and base area once every day, removing any lint or thread which may have accumulated. For this purpose, the jig plate can be removed from the machine. Switch off the machine, unscrew the needle plate and remove the lint with a soft brush.

Remove the jig drive guard and clean away any dust or lint which may have accumulated.

#### NOTE:

Never oil the jig drive wheel.

### 3 - OPERATING INSTRUCTIONS


#### 3.11 Regulating Foot Pressure on Jig

##### *Adjustment of Presser Pressure*

Turn the presser regulating screw clockwise to increase, and counterclockwise to decrease. Be sure to tighten the nut after adjustment. A foot pressure of approximately 1.5 to 2 kg will give best results on all materials.

#### 3.12 Emergency Stop

This is achieved by pressing the red Stop button. This will activate Emergency Stop sequence. Machine will not restart until Stop button is reset.





### 3 - OPERATING INSTRUCTIONS

#### 3.13 Needle and Thread

Selection of the proper needle depends on the material and thread used.

For selection of the proper needle and thread sizes refer to the table below:

|   | NEEDLE SIZE (NM)** | THREAD SIZE |      |           |       | NEEDLE SYSTEM |
|---|--------------------|-------------|------|-----------|-------|---------------|
|   |                    | COTTON      | SILK | SYNTHETIC | LINEN |               |
| A | 60                 | 100 - 80    | 140  | 200 - 150 |       | 134 R         |
|   | 70                 | 70 - 60     | 120  | 180 - 120 |       |               |
| B | 80                 | 60 - 50     | 100  | 120 - 100 |       | 134 R         |
|   | 90                 | 50 - 40     | 90   | 100 - 80  | 70    |               |
|   | 100                | 40 - 30     | 70   | 80 - 60   | 60    |               |
| C | 110                | 30 - 24     | 60   | 60 - 50   | 50    | 134 R         |
|   | 120                | 20          | 50   | 50 - 40   | 40    |               |
|   | 130                | 12          | 40   | 40 - 30   | 35    |               |
|   | 140                | 10          | 30   | 30 - 20   | 30    |               |

- A = LIGHT WEIGHT MATERIALS
- B = MEDIUM WEIGHT MATERIALS
- C = HEAVY WEIGHT MATERIALS
- NM\*\* = NEEDLE SIZE IN HUNDRETHS OF MM

## 4 - SETTING PROCEDURES

### 4.1 Jig Feed Mechanism

#### a) Feed Motion Timing

Time the feed motion to be completed when the descending needle is approximately 5mm above the material.

Alterations to the stitch length are made in the usual manner using the stitch regulator.

#### b) Drive Wheel Assembly (Figure 4.1)

To replace a worn drive wheel detach the drive arm (10) from the machine bed, unfasten the spherical rod and bearings (14) from the arm and the drive wheel housing. Next remove the bearing (22), free-wheel housing (20) and drive

wheel (18) complete from the arm. Using the two M5 holes in the drive wheel with two screws as an anchor, loosen nut (25) and remove drive wheel from bearing. When re-assembling care should be taken that all surfaces are clean and free from lint etc. The pivot spindle (17) should at this stage be lubricated with graphited grease before replacement into the drive wheel.

#### CAUTION:

ORDINARY GREASE OR LUBRICATING OIL IS NOT SATISFACTORY IN THE DRIVE WHEEL STUD HOUSING. USE A GREASE CONTAINING GRAPHITE OR MOLYBDENUM DISULPHIDE.




Figure 4.1

## 4 - SETTING PROCEDURES

The clutch is lubricated with oil and has an 'O'-ring on the bottom to prevent oil leakage. It is also covered with a 'Nilos' sealing ring to exclude dust and fibrous waste. The clutch should be lubricated lightly every 100 running hours with light machine oil (non-staining).

Ensure drive wheel does not foul on base of machine, when unit is tightened down.

### c) Drive Wheel Cylinder (Figure 4.1)

The rod and bearing (1) should be set so that when the cylinder is fully extended the drive wheel is taken 3mm past its contact position.

**CAUTION:**  
CHECK THIS SETTING BECAUSE, IF THE DRIVE WHEEL TRAVELS TOO FAR, IT WILL CONTACT AND DAMAGE THE PHOTOCCELL IF THE MACHINE IS RUN WITHOUT A JIG.

### d) Drive Wheel Surface

The driving surfaces of the wheel must not be contaminated with any lubricant or silicone Aerosols etc., as this will affect the feeding. Clean the tapered groove with solvent if contamination is suspected.

### 4.2 Dense Stitch Size

The size of the dense stitches themselves may be altered using the adjustment nut 2 on the dense stitch adjuster located underneath the machine bed. By loosening nut 1 and rotating nut 2 clockwise the size of the dense stitches will increase. When the correct size is achieved use nut 1 to lock nut 2 in position. See fig 4.2.




Figure 4.2

### 4.3 Number of Dense Stitches

The A.M.F. Reece controller is set to give a timed sequence of dense stitches at the start and end of stitching. These two conditions can be altered by tenths of a second to give longer or shorter length of dense stitch.

The speed of the dense stitch may be altered to faster or slower (see Section 5.3).



### 4.4 Needle Reverse

The Efka motor may be programmed to take the needle to its highest position, when thick cloth is being used. This allows the presser foot to be set higher without needle protruding. (see Section 12. Efka Manual 3.3, - Increments for Revision).

## 4 - SETTING PROCEDURES

### 4.5 Turn Arm / Variable Speed Setting Instructions

1. To obtain uniform stitching on radiused corners it is necessary to find the machine speed that is matched to the speed of the torque arm. This is done by altering slow saw speed in A.M.F. Reece controller (see Section 5.3.4). Small stitches on a corner indicate too fast a machine speed, so this would require the speed to be lowered. Large stitches at the corner indicate too slow a machine speed. Correct this by increasing speed in A.M.F. Reece controller.
2. Actuation of the torque arm is caused by the photocell being energised after it has cleared the first piece of tape on the corner of the jig. It is returned when it is de-energised by the second piece of tape which is placed after the corner. It is possible to turn approx. 175° (see Figure 4.5).



3. The turn arm has a 20mm cylinder fitted. This is in return position when torque arm is at rest, this is to allow jigs with internal radii to pass underneath. Also fitted to the torque unit are two flow controls, these restrict the exhausted air to ensure that the jig turns smoothly.

TAPE POSITION AT CORNERS (Guide only)

## 4 - SETTING PROCEDURES

### 4.6 Photo-Electric Switch




Fig. 1

Fig. 2

a) Hints on correct use

Do not use the sensor i explosive or ignition gas.

Never disassemble, repair nor taper with the sensor.

Do not apply excess voltage and current over rating.

Do not wire improperly such as reversing polarity.

Do not short-circuit load.

Do not remove protective cover from the sensor.

b) Indication

In addition to the operation (orange). Sensor has indicators that denotes the level (4 green and 1 red indicators). Use them for optical axis adjustment and maintenance.

c) Sensitivity adjustment


To adjusting of correctly follow those steps:

aa) Put the jig with black tape under the sensor. When the black tape is under the sensor, operator indicator must not lit and one or two incident level indicators have to lit (green) see figure 1a, 1b.

bb) Move the jig to the position without black tape. Here operator indicator has to lit and three or more incident indicators have to lit see figure 1d, 1e.

| Indicator status (L/OH)                   | Operation indicator (L/OH) | Incident level                          |
|---|----------------------------|---|
| <p>a)</p> <p>Not lit / Lit (see note)</p> | Not lit                    | Approx. 80% to 90% of operating level   |
| <p>b)</p>                                 | Not lit                    | Approx. 80% to 90% of operating level   |
| <p>c)</p>                                 | Not lit or lit             | Approx. 90% to 110% of operating level  |
| <p>d)</p>                                 | Lit                        | Approx. 110% to 120% of operating level |
| <p>e)</p>                                 | Lit                        | Approx. 120% min. of operating level    |


Fig. 3



If sensor doesn't work according points mentioned above change the position of sensitivity adjuster. Standard position for sensitivity adjuster is show in figure 2.

**5 - CONTROLLER, PROGRAM DESCRIPTION AND ELECTRICAL CIRCUIT DIAGRAM**



**Display**



The following screen is displayed after turning the machine on:




To get into the main machine menu and to list in this menu, use the cursor arrows





## 5 - CONTROLLER, PROGRAM DESCRIPTION AND ELECTRICAL CIRCUIT DIAGRAM

### 1. Systemcheck

#### 1.1. Input Test







1. Start Button  

2. Photocell  



#### 1.2. Output Test



Output can be tested by pressing  button



1. Knife  

2. Jig Flap  

3. Dense Stitch  

4. Jig Drive  

5. Jig Turn  

6. Jig Eject  

## 5 - CONTROLLER, PROGRAM DESCRIPTION AND ELECTRICAL CIRCUIT DIAGRAM

---

### 1.3. Position Test

Sewing motor function can be tested:


- by 1<sup>st</sup> press of **E** button the needle goes to the bottom position
- by 2<sup>nd</sup> press of **E** button the needle goes to the top position

## 2. Edit


1. For the first time after turning the machine on, the following screen will appear:



Enter the code 131



Select the program for editing by pressing **1** - **6** .





## 5 - CONTROLLER, PROGRAM DESCRIPTION AND ELECTRICAL CIRCUIT DIAGRAM

### 2.1. Program Parameters

| Nr. | Parameter    | Values             | Description  |
|-----|--------------|--------------------|--|
| 1   | Double Jig   | OFF / ON           | sewing of double-jig off / on  |
| 2   | 1Jig Corner  | NeDN / SISp / END? | 1st jig corner: needle stay down / sewing at slow speed / end of cycle           |
| 2a  | 1 C.Slow Sp  | 400 – 2600 [spm]   | 1st jig corner: speed of the slow sewing   |
| 3   | 2Jig Corner  | NeDN / SISp / END? | 2nd jig corner: needle stay down / sewing at slow speed / end of cycle           |
| 3a  | 2 C.Slow Sp  | 400 – 2600 [spm]   | 2nd jig corner: speed of the slow sewing   |
| 4   | 3Jig Corner  | NeDN / SISp / END? | 3rd jig corner: needle stay down / sewing at slow speed / end of cycle           |
| 4a  | 3 C.Slow Sp  | 400 – 2600 [spm]   | 3rd jig corner: speed of the slow sewing   |
| 5   | 4Jig Corner  | NeDN / SISp / END? | 4th jig corner: needle stay down / sewing at slow speed / end of cycle           |
| 5a  | 4 C.Slow Sp  | 400 – 2600 [spm]   | 4th jig corner: speed of the slow sewing   |
| 6   | K.DelayStart | OFF / ON           | delayed activation of the cutting knife off / on                                 |
| 6a  | Time ON/Tape | OFF / ON           | delay of the cutting knife activation determined by time (ON) / black-tape (OFF) |
| 6b  | K.DelayTime  | 0 – 9999 [ms]      | time of the cutting knife activation delay (when activation by time selected)    |
| 7   | K.DelayEnd   | OFF / ON           | delay of the cutting knife deactivation from the final black-tape                |
| 8   | Dense into C | OFF / ON           | dense-stitches sewing in the corners off / on                                    |
| 9   | Sta Den.Tim  | 0 – 9999 [ms]      | time of dense-stitches sewing from the sewing start                              |
| 10  | End Den.Tim  | 0 – 9999 [ms]      | time of dense-stitches sewing from the final black-tape                          |
| 11  | Set Den. Sp  | 400 – 2600 [spm]   | setting of the dense-stitches sewing speed                                       |
| 12  | Slow Sew Sp  | 400 – 2600 [spm]   | setting of the speed when “sewing at slow speed” is selected in a corner         |
| 13  | Needle DnSp  | 400 – 2600 [spm]   | setting of the speed when “needle-stay down” is selected in a corner             |
| 14  | Max Sew Sp   | 400 – 2600 [spm]   | setting of the maximum sewing speed  |
| 15  | J.Flapp Act. | OFF / ON           | jig flapping off / on  |
| 16  | Sp to Corne  | 400 – 2600 [spm]   | setting of the speed before reaching the first corner                            |

### 3. Counter

Day-Cnt: ...

- daily production counter delete by pressing

2

KNIFE  
OFF


Main-Cnt: ...

- total machine production counter

## 5 - CONTROLLER, PROGRAM DESCRIPTION AND ELECTRICAL CIRCUIT DIAGRAM

---

### 4. Sequence



a) By pressing **1** you activate the sequence-mode:

- **S: 0-0-0-0-0-0-** select the individual desired programs for the sequence by successive pressing

buttons **1** - **6**.

- This will be indicated by **Knife:ON Sequ: 1** on the main screen.

b) By pressing **2** you deactivate the sequence-mode.

## 6 - PNEUMATICS

---

The pneumatics are switched by a bank of solenoid valves located inside the cabinet door. Air is normally on the 'B' lines. When a solenoid valve is energised, the air is transferred to line 'A'.

### 6.1 JIG FLAP.

When solenoid is energised this allows air through line A1 causing jig flap to lift.

### 6.2 JIG TURN.

When solenoid is energised this allows air through line A2 causing turn arm to function and turn jig. When solenoid is de-energised this allows turn arm to return to rest position, air through line B2.

### 6.3 JIG DRIVE.

When solenoid is energised this allows air through line A3 causing jig eject cylinder to operate. When de-energised this allows air to line B3 causing jig eject cylinder to return.

### 6.4 JIG DRIVE.

When solenoid is energised this allows air through line A4 causing jig drive cylinder to operate and grip jig. When solenoid is de-energised this allows air through B4 causing jig drive to return.

### 6.5 KNIFE.

When solenoid is energised this allows air through line A5 causing knife to engage and allowing air to foot and rear blower. When solenoid is de-energised this allows air through B5 causing knife to return to up position, and removes air from waste blowers.


### 6.6 AIR BLOWERS.

There are three blowers fitted to the machine: one to the throat plate, one to the foot and one to the rear of the machine. All blowers should be set so they dispose of trimmed material to the rear of the machine.

### 6.7 AIR FLOW REGULATORS.

Most air cylinders are fitted with flow control valves, to adjust the speed of operation of the air piston. For example, drive wheel cylinder (fig 4.1, item 2) must be adjusted so that the drive wheel is brought smoothly into contact with the edge of the jig, otherwise damage may be caused to the jig.


# 6 - PNEUMATICS



## 7 - HEAD SETTING PROCEDURES

### 7.1 Needle Insertion.


Hold the lower punch mark of the needle '1' to face the left. Then make the end of the needle butt up to the upper side of the stopper hole '2'. Then secure the needle with the fixing screw '3'. (Refer to fig. 31)



[ Fig. 31 ]

### 7.2 Adjusting The Needle Bar.


As shown in Fig. 32, remove the rubber plug '4' from the front cover. Rotate the pulley to move the needle to its lowest position. Then release the needle fixing screw '5'. Align the upper punch mark '7' on the needle bar with the bottom end of the needle bar lower bushing '6' and then tighten the screw '5' and fit the rubber plug '4'.



[ Fig. 32 ]

### 7.3 Adjusting The Timing Of The Needle Hook.

As shown in fig. 32, align the lower punch mark of the needle bar '1' with the end of the lower needle bar bushing '6' and release the three fixing screws '2'. With the point of the hook '3' set to the centre of the needle adjust the point of the hook to give 0.05-0.1mm gap. Tighten the three screws '2'.



[ Fig. 33 ]

### 7.4 Adjusting The Lubrication of the Thread Take-up Lever.

As shown in fig. 33, when the dot '2' marked on the head of the oil adjusting pin '1' aligns with the centre of the thread-take up crank shaft hole '3', the maximum amount of oil is released. If the adjusting pin is turned towards the marks '5', the amount of oil released will be reduced. If the dot '2' passes marks '5', no oil will be released.

## 7 - HEAD SETTING PROCEDURES

### 7.5 Regulation Of Amount Of Oil Supply To Hook.


#### A. Measuring amount of oil supplied.

1. Run the sewing machine on full speed for 3 minutes. Place a piece of paper in position as shown in fig. 34, and run machine for a further 5 seconds. The amount of oil being supplied can now be seen.

2. Repeat this process a further 3 times making sure the oil being supplied is within the limits shown in fig 34.  
 Too much oil could stain the material being sewn. Too little can cause the hook to seize.


#### B. Oil Supply Adjustment.

Turning the adjusting screw clockwise, as shown in fig. 34, will increase the oil flow, turning the screw counter clockwise will **Decrease** the oil flow.



[ Fig. 34 ]

### 7.6 Lower Thread Take Up and Tension Adjustment.



[ Fig. 35 ]

#### A. Spool Fitting and Tension Adjustment.

Refer to fig 35. Fit the spool '2' into the spool case '5.' Insert the thread spool in the groove '3.' Then hook the thread under the thread tension adjusting spring '4.' Rotating the tension adjusting screw '5' clockwise, increases the thread tension, rotating the tension adjusting screw '5' anti-clockwise decreases the thread tension. Adjust the thread tension so that the spool case will gradually drop under its own weight.


#### B. Insertion and Removal of Spool Case.

Refer to fig 35. Hold the spool case lever '1' and push the case into the hook. When removing, hold the spool case lever' and pull it out of the hook.


## 7 - HEAD SETTING PROCEDURES

### 7.7 Upper Thread Path.

Place the thread at the optimum position, then insert the upper thread according to the sequential numbers in fig. 36, 37.



[ Fig. 36 ]



[ Fig. 37 ]

### 7.8 Upper Thread Adjustment.

#### A. Main Thread Adjusting.

As shown in fig. 38, turning the tension adjusting screw '1' clockwise increases the upper thread tension. Adjust the tension of the thread according to the material being sewn, the thread and the number of stitches.

#### B. Tension Adjustment of Check Spring.


As shown in fig. 38, rotating screw '2' will increase the check spring tension.

#### C. Thread Pre-Tension Adjustment.


As shown in fig.39, rotating the pre-tension screw '1' clockwise, the length of trimmed thread will be reduced. The optimum length of the remaining thread after trimming is 30-40mm.

#### D. Adjusting Thread Release Unit.

The thread release unit is operated by the movement of the thread trimming actinoid. As shown in fig. 40 the thread release gap can be adjusted by moving the thread release cable wire '2' which is attached to the thread release operation lever '1'. Release the two fixing nuts '3'. Then move the cable wire '2' to the left and tighten the nuts '3'. The thread release gap will have increased. If the cable '2' is moved to the right the gap will be decreased. Adjust the cable to give a gap of 0.5-1mm between the discs '4' when the thread release is operated. Ensure the discs are closed when the lever is released. The stroke of the thread release lever '1' is 5mm. Adjust the lever so that the discs '4' do not open during the first 2mm of lever travel and that they are open when the lever is pulled 2-5mm. Refer to fig. 40.




[ Fig. 38 ]



[ Fig. 39 ]

## 7 - HEAD SETTING PROCEDURES




[ Fig. 40 ]

### 7.9 Presser Foot Height and Pressure Adjustment.

A. As shown in fig. 41, remove the rubber plug '2' from the cover plate '1.' With the needle in the 'up' position and the presser foot '3' also in the 'up' position make sure the needle point is not showing below the presser foot. If the needle point is visible then release the presser bar holder screw '4' and adjust the holder until the foot covers the needle. Once the adjustment has been carried out check the presser foot will both clamp the jig in the 'down' position and also allow the jig to be loaded in the 'up' position.


B. Adjustment of the presser foot pressure. As shown in fig. 41 rotating the adjusting screw '5' clockwise increases the foot pressure. After adjustment use nut '7' to lock adjusting screw '5' in position.



[ Fig. 41 ]

### 7.10 Presser Foot Solenoid Adjustment.

Presser foot travel can be adjusted on the presser foot solenoid crank '3.' Referring to fig. 42 Release the screws '5' securing the solenoid cover '4'. Release screw '2' for the solenoid crank pivot. Rotating the pivot '1' clockwise will increase the foot travel, anti clockwise will reduce the presser foot travel.






## 7 - HEAD SETTING PROCEDURES

### 7.11 Stitch Length Adjustment.


As shown in fig. 43 the dial '1' increases stitch size when turned anti-clockwise and reduces the stitch size when turned clockwise.



[ Fig. 43 ]

### 7.12 Feed Cam Adjustment.

When the feed timing is correct the jig should be moved just after the needle has left the material. To obtain this timing remove the plate holding the presser foot lift solenoid and locate the feed cam '1' as shown in fig. 46. After releasing screw '2,' rotate the cam clockwise to advance the feed, or rotate the cam counter clockwise to retard the feed. Tighten screw '2' when finished.




[ Fig. 46 ]

## 7 - HEAD SETTING PROCEDURES


### 7.13 Thread Trimming Timing Adjustment.

- A. Referring to fig. 48 line up mark '2' on hand wheel with punch mark '3' on head.
- B. Remove spring '4' as shown in fig. 48.




[ Fig. 48 ]

- C. Referring to fig. 49, push trimming blade '8' up until fixed knife '9' is 1-1.5mm onto mound '7'.
- D. Referring to fig. 49, push thread trimming solenoid '10' in with screw '9' of the thread trimming cam slackened. The distance between trimming cam '11' and roller screw '12' is 0.5mm.



[ Fig. 49 ]

- E. Tighten up screw '9' for the thread trimming cam after adjustment. Check the roller of cam '11' with roller '14' by rotating thread trimming cam '11' by hand. Refer to fig. 50.
- F. Connect return spring '4'.




[ Fig. 50 ]

## 7 - HEAD SETTING PROCEDURES

### 7.14 Fixed Knife Tension Adjustment.


Release the tension adjusting nut '1' with a box spanner and release the tension adjusting screw '2.' As shown in fig. 51 push the moving knife towards the fixed knife until its blade point meets the fixed knife point. Tighten the fixed knife tension adjusting screw '2' until the two blades touch without force. Tighten the tension adjusting nut '1.'



[ Fig. 51 ]

### 7.15 Replacing The Moving Knife.

Ensure the needle is in the 'up' position and remove the throat plate. Referring to fig. 52 undo the two screws '2' and remove the moving knife '1.' Fit the new knife and tighten all screws.




[ Fig. 52 ]

### 7.16 Replacing The Fixed Knife.


A. To replace the fixed knife '1' release the spool case positioning finger fixing screw '2' as shown in fig. 53 and remove washer '3' and finger '4.'

Remove the fixed knife screw '5' and then remove the fixed knife.



[ Fig. 53 ]


B. If the point of the blade is dull sharpen using an oil stone. Refer to fig 54.



[ Fig. 54 ]

### 7.17 Bobbin Catcher Adjustment.

As shown in fig. 55 with the spool catcher lever '3' relaxed, release the fixing screws '6' and adjust the lever '3' until it is touching the bottom of the connector link '2' as shown by 'a.'




[ Fig. 55 ]

## 7 - HEAD SETTING PROCEDURES

### 7.18 Side Knife Replacement and Adjustment.

When the knife is engaged it should cut cloth cleanly without having excessive pressure on the throat plate.

Referring to fig. 56 loosen screws '1' and remove knife '2.' Insert new knife and, with the knife in it's lowest position, adjust knife holder '4' by releasing screw '3' and pushing knife upto throat plate. Tighten all screws.



[ Fig. 56 ]

## 7 - HEAD SETTING PROCEDURES

### 7.19 Sewing Head Trouble Shooting.

| NO | Problem   | Check   | Cause  | Maintenance                      |
|----|---|---|--|----------------------------------|
| 1  | The needle is broken                              | Needle facing.  | The needle is inserted incorrectly             | Replace the needle correctly     |
|    |   | Needle  | The needle is bent                             | Replace the needle               |
|    |   |   | Improper feed dog timing                       | Adjust the operating time        |
|    |   | Raised height of the needle bar   | Improper needle and rotary hook timing         | Adjust the operating time        |
|    |   | Height of the needle bar  | Improper needle and rotary hook timing         | Adjust the operating time        |
| 2  | The thread is out.                                | Clearance between the needle and the hook   | Improper needle and rotary hook timing         | Adjust the operating time        |
|    |   | Threading   | Threading is incorrect                         | Rethread it                      |
|    |   | Needle  | The needle is bent or damaged                  | Rethread the needle              |
|    |   | Needle facing and height  | The needle is incorrectly inserted             | Reinstall the needle correctly   |
|    |   | Upper thread tension  | The tension is too tight                       | Adjust the tension adequately    |
| 3  | The stitching is messed over                      | Lower thread tension  | The tension is too tight                       | Adjust the tension adequately    |
|    |   | Stroke of the thread take up spring   | The upper thread is loose                      | Adjust the thread take-up spring |
|    |   | Needle facing and height  | The needle is inserted incorrectly             | Reinstall the needle correctly   |
|    |   | Needle  | Needle is bent or damaged                      | Replace the needle               |
|    |   | Threading   | Threading is incorrect                         | Replace the needle               |
|    |   | Raised height of the needle bar   | Improper needle and rotary hook timing         | Adjust the operating time        |
|    |   | Height of the needle bar  | Improper needle and rotary hook timing         | Adjust the operating time        |
|    |   | Clearance between the needle and the hook   | Improper needle and rotary hook timing         | Adjust the operating time        |
|    | Remains of the upper thread is too short          | Adjust it with the thread tension adjusting unit.   |  |                                  |
|    | Bobbin case spring or pre-winding bobbin rotation | During the thread spinning, the bobbin rotates abnormally. So, the bobbin thread coming from the bobbin case is too short or is taken up. | Change the spring or pre-winding the bobbin.   |                                  |
|    | Thread take-up spring                             | The tension of the thread take-up spring is too loose to raise up the bobbin thread.  | Adjust the stroke of the thread take-up spring |                                  |

## 8 - SYNCHRONISER

### 8.5 SYNCHRONISER SETTING

#### 8.5 Synchroniser (Figure 8.5)

When sawing is interrupted with trim signal the machine should first stop with the needle bar positioned about 4mm past bottom dead centre, then proceed to trim and stop in take up lever up position.


- a) Check the trimming speed, this should be 180 r.p.m. For adjustment, refer to EFKA manual (parameter 110 - section 7.4).
- b) Remove the protecting cap of the synchroniser.
- c) Display the EFKA motor stop positions (Parameter 172 - see EFKA manual, section 7.8).
- d) Use the AMF Reece controller to position needle down (alternatively, use the EFKA hand plunger),

Holding the central disk with pliers, turn the hand wheel anti clockwise, until the needle reaches the lowest position. Then, keep turning the hand wheel past this position slightly, so that the lower of the two needle bar markers shows below the sewing head.

- e) Use the AMF Reece controller to position needle up.

Holding the outer disk with pliers, turn the hand wheel anti clockwise, until the needle reaches the highest position. Then, turn the hand wheel slightly, so that the thread take up lever is in it's top turning point.

- f) Check that the gap between the inner and central disks is 25mm.
- g) Check both needle up and needle down positions.




**Parameter list for machines AJ 84-72MJ**

EFKA MOTOR DRIVER: AB211A

| Parameter  | Setting   |
|------------|---|
| 290        | 00  |
| 272        | 1000 +/-1   |
| <b>401</b> | 1 <span style="float: right;">Storage the changed parameter values</span>   |
| 110        | 180   |
| 111        | 2600  |
| 153        | 03  |
| 161        | 1   |
| 180        | 005   |
| 181        | 010   |
| 182        | 1   |
| 202        | 200   |
| 204        | 020   |
| 207        | 8   |
| 208        | 8   |
| 213        | 40  |
| 219        | 5   |
| 220        | 5   |
| 225        | 8   |
| 240        | 16  |
| 270        | 3   |
| 780        | 150   |
| 781        | 500   |
| 782        | 500   |
| 783        | 1000  |
| 784        | 1000  |
| <b>401</b> | 1 <span style="float: right;">Storage the changed parameter values</span>   |
| 171        | 1. Sr2 Appears: Press >><br>2. P1E Appears: Move the needle to the lowest position by hand-wheel and write down P1E value; Press <b>E</b><br>3. P2E Appears: Move the needle to the topmost position by hand-wheel and write down P2E value; Press <b>E</b><br>4. P1A Appears: Calculate the position $P1A = P1E+60$ and move the machine to this position by hand-wheel; Press <b>E</b><br>5. P2A Appears: Calculate the position $P2A = P2E+60$ and move the machine to this position by hand-wheel; Press <b>E</b> |
| <b>401</b> | 1 <span style="float: right;">Storage the changed parameter values</span>   |

Setting Display:



Programming the Code Number:

Press the **P** key and turn power on.

Supplier code: **3112**      Technical code: **5913**

Press the **P** key to exit programming mode

**Important!**

Storage the changed parameter values: Input parameter **401**=set 1. Press E or P.

All data are stored.

Use manual EFKA for more information!

## Programs manufacturer setting

Program 1



| Nr. | Parameter    | Values |
|-----|--------------|--------|
| 1   | Double Jig   | OFF    |
| 6   | K.DelayStart | ON     |
| 6a  | Time ON/Tape | ON     |
| 6b  | K.DelayTime  | 200    |
| 7   | K.DelayEnd   | ON     |
| 8   | Dense into C | OFF    |
| 9   | Sta Den.Tim  | 600    |
| 10  | End Den.Tim  | 1000   |
| 11  | Set Den. Sp  | 400    |
| 12  | Slow Sew Sp  | 400    |
| 13  | Needle DnSp  | 600    |
| 14  | Max Sew Sp   | 2600   |
| 15  | J.Flap Act.  | ON     |
| 16  | Sp to Corne  | 2600   |

Program 2



| Nr. | Parameter    | Values |
|-----|--------------|--------|
| 1   | Double Jig   | ON     |
| 6   | K.DelayStart | ON     |
| 6a  | Time ON/Tape | ON     |
| 6b  | K.DelayTime  | 200    |
| 7   | K.DelayEnd   | ON     |
| 8   | Dense into C | OFF    |
| 9   | Sta Den.Tim  | 600    |
| 10  | End Den.Tim  | 1000   |
| 11  | Set Den. Sp  | 400    |
| 12  | Slow Sew Sp  | 400    |
| 13  | Needle DnSp  | 600    |
| 14  | Max Sew Sp   | 2600   |
| 15  | J.Flap Act.  | ON     |
| 16  | Sp to Corne  | 2600   |

Program 3



| Nr. | Parameter    | Values |
|-----|--------------|--------|
| 1   | Double Jig   | OFF    |
| 2   | 1Jig Corner  | NeDN   |
| 3   | 2Jig Corner  | NeDN   |
| 4   | 3Jig Corner  | END?   |
| 5   | 4Jig Corner  | END?   |
| 6   | K.DelayStart | ON     |
| 6a  | Time ON/Tape | ON     |
| 6b  | K.DelayTime  | 200    |
| 7   | K.DelayEnd   | ON     |
| 8   | Dense into C | OFF    |
| 9   | Sta Den.Tim  | 600    |
| 10  | End Den.Tim  | 1000   |
| 11  | Set Den. Sp  | 400    |
| 12  | Slow Sew Sp  | 400    |
| 13  | Needle DnSp  | 600    |
| 14  | Max Sew Sp   | 2600   |
| 15  | J.Flap Act.  | ON     |
| 16  | Sp to Corne  | 2600   |

Program 4



| Nr. | Parameter    | Values |
|-----|--------------|--------|
| 1   | Double Jig   | OFF    |
| 2   | 1Jig Corner  | SISp   |
| 2a  | 1 C.Slow Sp  | 400    |
| 3   | 2Jig Corner  | SISp   |
| 3a  | 2 C.Slow Sp  | 400    |
| 4   | 3Jig Corner  | END?   |
| 5   | 4Jig Corner  | END?   |
| 6   | K.DelayStart | ON     |
| 6a  | Time ON/Tape | ON     |
| 6b  | K.DelayTime  | 200    |
| 7   | K.DelayEnd   | ON     |
| 8   | Dense into C | OFF    |
| 9   | Sta Den.Tim  | 600    |
| 10  | End Den.Tim  | 1000   |
| 11  | Set Den. Sp  | 400    |
| 12  | Slow Sew Sp  | 400    |
| 13  | Needle DnSp  | 600    |
| 14  | Max Sew Sp   | 2600   |
| 15  | J.Flap Act.  | ON     |
| 16  | Sp to Corne  | 2600   |

Program 5



| Nr. | Parameter    | Values |
|-----|--------------|--------|
| 1   | Double Jig   | OFF    |
| 2   | 1Jig Corner  | NeDN   |
| 3   | 2Jig Corner  | END?   |
| 4   | 3Jig Corner  | END?   |
| 5   | 4Jig Corner  | END?   |
| 6   | K.DelayStart | ON     |
| 6a  | Time ON/Tape | ON     |
| 6b  | K.DelayTime  | 200    |
| 7   | K.DelayEnd   | ON     |
| 8   | Dense into C | OFF    |
| 9   | Sta Den.Tim  | 600    |
| 10  | End Den.Tim  | 1000   |
| 11  | Set Den. Sp  | 400    |
| 12  | Slow Sew Sp  | 400    |
| 13  | Needle DnSp  | 600    |
| 14  | Max Sew Sp   | 2600   |
| 15  | J.Flap Act.  | ON     |
| 16  | Sp to Corne  | 2600   |


Program 6



| Nr. | Parameter    | Values |
|-----|--------------|--------|
| 1   | Double Jig   | OFF    |
| 2   | 1Jig Corner  | SISp   |
| 2a  | 1 C.Slow Sp  | 400    |
| 3   | 2Jig Corner  | END?   |
| 4   | 3Jig Corner  | END?   |
| 5   | 4Jig Corner  | END?   |
| 6   | K.DelayStart | ON     |
| 6a  | Time ON/Tape | ON     |
| 6b  | K.DelayTime  | 200    |
| 7   | K.DelayEnd   | ON     |
| 8   | Dense into C | OFF    |
| 9   | Sta Den.Tim  | 600    |
| 10  | End Den.Tim  | 1000   |
| 11  | Set Den. Sp  | 400    |
| 12  | Slow Sew Sp  | 400    |
| 13  | Needle DnSp  | 600    |
| 14  | Max Sew Sp   | 2600   |
| 15  | J.Flap Act.  | ON     |
| 16  | Sp to Corne  | 2600   |



**WIRING DIAGRAM FOR THE AJ 84-72  
DISPLAY V850 EFKA**





EXTERNAL D CONNECTOR HARNESS  
 AMF CODE - **06.8400.1.005**

From EFKA ST2 connector

|                                   |                   |        |  |      |
|-----------------------------------|-------------------|--------|--|------|
| FROM EFKA 'D' CONN. PIN <b>33</b> | — <b>RED 0.35</b> | ○ 1 ○  | 24 V RED FROM SOLENOID'S                     |      |
| FROM EFKA 'D' CONN. PIN <b>24</b> | — <b>GREEN</b>    | ○ 2 ○  | BLACK FROM JIG FLAP SOLENOID                 | No.1 |
| FROM EFKA 'D' CONN. PIN <b>25</b> | — <b>PINK</b>     | ○ 3 ○  | BLACK FROM JIG TURN SOLENOID                 | No.2 |
| FROM EFKA 'D' CONN. PIN <b>23</b> | — <b>VIOLET</b>   | ○ 4 ○  | BLACK FROM JIG EJECT SOLENOID                | No.3 |
| FROM EFKA 'D' CONN. PIN <b>29</b> | — <b>BROWN</b>    | ○ 5 ○  | BLACK FROM JIG DRIVE SOLENOID                | No.4 |
| FROM EFKA 'D' CONN. PIN <b>36</b> | — <b>GREY</b>     | ○ 6 ○  | BLACK FROM KNIFE SOLENOID                    | No.5 |
|                                   |                   | ○ 7 ○  |  |      |
| FROM EFKA 'D' CONN. PIN <b>17</b> | — <b>RED</b>      | ○ 8 ○  | 24V FROM PHOTOCELL BROWN+START/STOP SWITCHES |      |
| FROM EFKA 'D' CONN. PIN <b>4</b>  | — <b>BLUE</b>     | ○ 9 ○  | 0 V FROM PHOTOCELL BLUE                      |      |
| FROM EFKA 'D' CONN. PIN <b>8</b>  | — <b>BLACK</b>    | ○ 10 ○ | BLACK FROM PHOTO CELL                        |      |
| FROM EFKA 'D' CONN. PIN <b>11</b> | — <b>WHITE</b>    | ○ 11 ○ | WHITE FROM START BUTTON                      |      |
| FROM EFKA 'D' CONN. PIN <b>6</b>  | — <b>YELLOW</b>   | ○ 12 ○ | GREEN FROM EMERGENCY STOP                    |      |

TERMINAL STRIP  
 AMF CODE - **12.008.4.845**

## TROUBLESHOOTING

### 9.1 Stitching

| FAULT                                      | CAUSE   | CORRECTION  |
|--|---|---|
| 9.1.1 Random thread breakage               | Problem with thread path (including the throat plate and presser foot). | Remove burrs from thread path.  |
|  | Problem with the sewing hook.   | Remove burrs, clean & polish. Check the hook point. Check the clearance between the hook and the bobbin case opener lever. Check lubrication. |
|  | Thread is caught somewhere in the thread path.                          | Correct threading.  |
|  | Tension is wrong.   | Adjust tension.   |
|  | Thread take-up spring misadjusted.                                      | Adjust the take-up.   |
|  | Problem with needle.  | Check or replace.   |
|  | Spool spin.   | Fit friction washer.  |
|  | Material wrongly positioned in jig.                                     | Ensure all stitching is in material.  |
| 9.1.2 Slip stitching                       | Jig damage.   | Repair jig.   |
|  | Problem with the needle.  | Check for needle damage and for correct needle orientation. Check that the needle size is correct for the thread being used.                  |
|  | Problem with the sewing hook.   | Check to see if the hook point is blunt or worn. Check the hook timing.   |
|  | Needle thread tension is too high.                                      | Decrease the tension.   |
|  | Sewing head speed is too high.  | Reduce the motor speed.   |
|  | Thread take-up spring misadjusted.                                      | Adjust the take-up.   |
|  | Material flagging.  | Check jig is clamping material. Check presser foot.   |
| 9.1.3 Short end on top or needle unthreads | Tension release mechanism.  | Check that tension release is functioning properly.   |
|  | Underbed moving knife or counter knife out of setting.                  | Reset trimming, section 8.  |

## TROUBLESHOOTING

| 9.1 Stitching |  |  |   |
|---------------|--|--|---|
|               | FAULT  | CAUSE  | CORRECTION  |
| 9.1.4         | Thread not trimmed                                   | Thread catcher moved.  | Reset synchroniser and trimming.  |
|               |  | Loose plug on solenoid lead.   |   |
|               |  | Loose plug on synchroniser.  |   |
|               |  | Synchroniser loose on handwheel.                                       | Reset synchroniser, section 8.  |
|               |  | Sewing hook slipping last stitch.                                      | Check to see if hook point is blunt or worn. Check hook timing.   |
|               |  | Blunt or misadjusted thread trimming knives.                           | Check knives.   |
| 9.1.5         | Thread not picked up                                 | Short end on spool thread due to "Spool Spin".                         | Increase the the pressure of the bobbin case holder positioning finger. Increase the bobbin thread tension. |
|               |  | The pressure of the bobbin case holder positioning finger is too high. | Decrease pressure of the finger, but check for "spool spin" - see above.                                    |
| 9.1.5         | Spool thread picked up late after first few stitches | Short end on needle thread.  | Correct as 9.1.3.   |
|               |  | Short end on spool thread.   | Correct as 9.1.5.   |
| 9.1.7         | First few stitches looped underneath                 | Foot lift cylinder sluggish on return.                                 | Remove, clean and lubricate.  |

## TROUBLESHOOTING

---

### 9.2 Machine Controls

| FAULT                           | CAUSE                                      | CORRECTION                                |
|---------------------------------|--|---|
| 9.2.1 Machine fails to start    | Jig in wrong position                      | Reset and return jig to machine correctly |
|                                 | Excessive cloth thickness jig              |   |
|                                 | Drop in air pressure                       | Check 90 PSI (6.5 Bars) on gauge          |
|                                 | Din plug loose                             | Re-connect                                |
|                                 | Synchroniser plug out                      | Re-connect                                |
|                                 | Wire off start button                      | Re-solder                                 |
| 9.2.2 Machine fails to stop     | No tape at end                             | Add tape                                  |
|                                 | Photo-cell missing tape                    | Re-position tape                          |
|                                 | Photo-cell not clearing tape at end of jig | Re-position tape                          |
| 9.2.3 Machine fails to position | Wrongly programmed in Elka motor           | See Section 8.5 Needle positions          |
| 9.2.4 Machine runs slow         | Missed a signal from tape<br>Photo-cell    | Check position of tape                    |

## TROUBLESHOOTING

### 9.3 Feed


| FAULT                                     | CAUSE   | CORRECTION  |
|---|---|---|
| 9.3.1 Small stitches                      | Worn drive wheel                              | Replace   |
|   | Damaged jig                                   | Repair  |
|   | Excessive foot pressure                       | Reset to 1.5 - 2.0 kg   |
| 9.3.2 Large stitches                      | Presser foot not in contact with jig          | Re-set presser bar, Section 3.10  |
|   | Pressure foot pressure almost zero            | Re-set to 1.5 - 2.0 kg  |
| 9.3.3 Dense stitch fails to operate       | Feed lever adjustment bracket screw loose     | Re-set and tighten  |
| 9.3.4 Large stitches on corner            | Corner speed too slow                         | Adjust speed by altering corner speed in A.M.F. Reece controller, Section 5.3.4 |
|   | Turn cyl movement too fast                    | Slow down through flow control  |
| 9.3.5 Small stitches on corner            | Corner speed too fast                         | Adjust speed by altering corner speed in A.M.F. Reece controller, Section 5.3.4 |
|   | Turn cyl movement too slow                    | Speed up through flow control   |
| 9.3.6 Irregular profile at corner         | Needle down switch selection for round corner | Switch to slow run position   |
| 9.3.7 Jig fails to stitch slow at corners | No signal<br>check tape position              | Reset tape position check photo-cell receiving signal                           |
| 9.3.8 Jig fails to stitch a sharp corner  | Photo-cell faulty                             | Replace   |
|   | Sensitivity                                   | Re-set to sense black tape on jig   |
|   | Wrong program selected                        | Select correct program  |

## TABLE OF CONTENTS

---

|  |      |
|--|------|
| ELECTRICAL AND PNEUMATIC COMPONENTS..... | 3-2  |
| JIG DRIVE/JIG EJECT/SNUBBER.....         | 3-6  |
| PRESSER FOOT/JIG FLAP/AMPLIFIER.....     | 3-10 |
| TURN ARM.....                            | 3-12 |
| HEAD AND SYNCHRONIZER.....               | 3-14 |
| KNIFE MECHANISM.....                     | 3-15 |

# ELECTRICAL AND PNEUMATIC COMPONENTS






**ELECTRICAL AND PNEUMATIC COMPONENTS**

| DET | PART NUMBER   | DESCRIPTION               | QTY |
|-----|---------------|---------------------------|-----|
| 1   | 12.0010.4.101 | Efka On/Off Box           | 1   |
| 2   | 84.0004.6.865 | Pressure Gauge            | 1   |
| 2   | 84.0002.0.727 | 1/8" Sleeve Coupler       | 1   |
| 2   | 84.0003.2.100 | 1/8"-4mm Adaptor          | 1   |
| 3   | 84.0005.8.625 | Rubber Grommet 6,4        | 1   |
| 4   | 84.0005.8.627 | Rubber Grommet 15.5       | 5   |
| 5   | 84.0005.7.110 | Electrical Cabinet        | 1   |
| 7   | 84.0004.6.795 | 12 Way Terminal Strip     | 1   |
| 9   | 84.0005.7.095 | Frame                     | 1   |
| 10  | 84.0003.2.110 | Straight Fitting 4mm      | 1   |
| 11  | 84.0004.6.746 | Pilot Valve               | 1   |
| 12  | 84.0003.2.095 | Elbow 4mm                 | 1   |
| 13  | 84.0002.1.085 | M3 Nut                    | 2   |
| 14  | 84.0006.0.989 | 'T' Connector 4mm         | 1   |
| 15  | 84.0003.2.150 | 'T' Connector 4mm         | 1   |
| 16  | 84.0002.0.845 | M3x20 Cap Hd Screw        | 1   |
| 17  |               | M3x20 Cap Hd Screw        | 1   |
| 18  | 84.0003.2.105 | 6mm Elbow                 | 1   |
| 19  | 84.0005.7.125 | 5 Station Manifold        | 1   |
| 20  | 84.0004.6.847 | Push in Fitting, 5mm      | 10  |
| 21  | 84.0002.0.852 | M4x25 Cap Hd Screw        | 2   |
| 22  | 84.0002.1.092 | M4 Plain Washer           | 2   |
| 23  | 84.0002.1.026 | M4 Spring Washer          | 2   |
| 24  | 84.0002.1.085 | M4 Nut                    | 2   |
| 25  | 84.0003.2.107 | 1/4"-M6 Elbow Adaptor     | 1   |
| 26  |               | M5x12 Butt Hd Screw       | 2   |
| 27  | 84.0004.6.940 | M5 Aluminum Rivnut        | 2   |
| 28  | 84.0003.2.015 | Bracket                   | 1   |
| 29  | 84.0004.8.045 | Filter Regulator          | 1   |
| 30  | 84.0003.2.108 | 1/4"-6mm in line Adaptor  | 1   |
| 31  | 84.0003.2.155 | 1/8"-4mm Branch T Adaptor | 1   |
| 32  | 06.8400.1.011 | Efka Driver               | 1   |
| 32  | 12.0010.4.327 | Motor Efka                | 1   |
| 32  | 06.8400.1.005 | Cable ST2 Assembly        | 1   |
| 32  | 84.0005.8.680 | Filter                    | 1   |
| 33  |               | Wood Screw                | 6   |
| 34  | 84.0005.7.115 | Brace, L/H                | 1   |
| 34  | 84.0005.7.116 | Brace, R/H                | 1   |
| 35  | 84.0002.0.982 | M5x10 Butt Hd Screw       | 6   |
| 36  | 84.0005.7.146 | Table Top                 | 1   |
| 37  | 84.0002.1.068 | Motor Mounting Bolt       | 3   |
| 38  | 84.0002.1.058 | M8 Nut                    | 3   |
| 38  | 84.0002.1.093 | M8 Washer                 | 3   |
| 39  | 84.0004.7.150 | Drive Belt                | 1   |
| 40  | 12.0010.4.099 | Contact Block NO          | 1   |



# ELECTRICAL AND PNEUMATIC COMPONENTS




**ELECTRICAL AND PNEUMATIC COMPONENTS**


| DET | PART NUMBER   | DESCRIPTION             | QTY |
|-----|---------------|-------------------------|-----|
| 41  | 84.0002.0.948 | No. 6x5/8" Pan Hd Screw | 4   |
| 42  | 84.0004.8.455 | Stop Start Plate        | 1   |
| 43  | 12.0008.4.583 | Start Button            | 1   |
| 43  | 12.0010.4.098 | Clip                    | 1   |
| 44  | 12.0008.4.584 | Stop Button             | 1   |
| 44  | 12.0010.4.098 | Clip                    | 1   |
| 45  | 12.0010.4.102 | Contact Block NC        | 1   |
| 46  | 84.0002.5.490 | Nylon Grommet           | 3   |
| 47  | 84.0003.2.105 | Elbow 6mm               | 1   |
| 48  | 84.0004.6.806 | Small Cable Gland       | 1   |
| 49  |               | Wood Screw              | 2   |
| 50  | 84.0003.2.120 | Air Valve On/Off        | 1   |
| 51  | 84.0010.7.350 | Bracket                 | 1   |
| 52  | 84.0002.0.719 | Elbow 1/4"x8mm          | 1   |
| 53  | 84.0002.0.871 | M6x50 Cap Hd Screw      | 2   |
| 54  | 84.0002.1.099 | M6 Plain Washer         | 2   |
| 55  | 84.0002.1.088 | M6 Nut                  | 2   |
| 56  | 84.0002.1.028 | M6 Spring Washer        | 2   |
| 58  | 84.0004.6.565 | Control Box Mntg. Bkt   | 1   |
| 59  | 84.0002.0.851 | M4x16 Cap Hd. Screw     | 4   |
| 60  | 12.0010.4.325 | Display V850 Efka       | 1   |
| 62  | 84.0002.0.878 | M4x10 Cap Hd Screw      | 1   |
| 62  | 84.0002.1.086 | M4 Nut                  | 1   |
| 62  | 84.0002.1.092 | M4 Plain Washer         | 1   |
| 62  | 84.0002.0.843 | M3x12 Cap Hd Screw      | 1   |
| 62  | 84.0002.1.085 | M3 Nut                  | 1   |
| 63  | 84.0002.0.851 | M4x16 Cap Hd. Screw     | 4   |
| 64  | 84.0002.1.086 | M4 Nut                  | 4   |
| 65  | 84.0004.8.994 | Panduit Connector       | 1   |
| 66  | 84.0004.8.995 | Panduit Connector Cover | 1   |
| 66  | 84.0004.8.996 | Polarizing Pin          | 3   |
| 67  | 84.0005.9.684 | Screw 3/16-28x15        | 1   |
| 68  | 08.6000.5.012 | Screw M5x12             | 1   |
| 69  | 08.6850.5.000 | Washer 5,3              | 1   |
| 70  | 84.0005.9.683 | Screw 3/16-28x12        | 1   |

*Not Illustrated:*

|               |                     |   |
|---------------|---------------------|---|
| 84.0005.8.680 | 5/6mm Ferrite       | 3 |
| 84.0005.8.682 | 6.5 Ferrite         | 3 |
| 84.0005.8.684 | 13mm Hinged Ferrite | 1 |

# JIG DRIVE/JIG EJECT/SNUBBER




## JIG DRIVE/JIG EJECT/SNUBBER

| DET              | PART NUMBER   | DESCRIPTION            | QTY |
|------------------|---------------|------------------------|-----|
| <b>JIG DRIVE</b> |               |                        |     |
| 1                | 84.0004.8.085 | Drive Arm              | 1   |
| 2                | 84.0004.6.935 | Drive Cover Stud       | 1   |
| 3                | 84.0003.0.511 | Mounting Arm Eccentric | 1   |
| 4                | 84.0002.1.088 | M6 Nut                 | 1   |
| 5                | 84.0002.1.087 | M5 Nut                 | 1   |
| 6                | 84.0002.1.098 | M5 Plain Washer        | 1   |
| 7                | 84.0002.0.984 | M5x16 Butt Hd Screw    | 4   |
| 8                | 84.0002.9.060 | Stud                   | 1   |
| 9                | 84.0002.8.200 | Rod End                | 2   |
| 10               | 84.0004.6.535 | Oil Cover Tube         | 1   |
| 11               | 84.0004.6.530 | Oil Cover              | 1   |
| 12               | 84.0002.0.855 | M4x30 Cap Hd Screw     | 1   |
| 13               | 84.0002.1.026 | M4 Spring Washer       | 1   |
| 14               | 84.0002.0.922 | M5x5 Grub Screw        | 2   |
| 15               | 84.0002.5.280 | Pivot Spindle          | 1   |
| 16               | 84.0002.9.010 | Drive Wheel            | 1   |
| 17               | 84.0002.9.125 | "O" Ring               | 1   |
| 18               | 84.0002.5.290 | Free Wheel Housing     | 1   |
| 19               | 84.0004.6.920 | Drive Plate            | 1   |
| 20               | 84.0002.0.842 | M3x10 Cap Hd Screw     | 2   |
| 21               | 84.0002.9.070 | Bearing                | 1   |
| 22               | 84.0002.9.126 | Nilos Ring             | 1   |
| 23               | 84.0002.9.020 | Washer                 | 1   |
| 24               | 84.0002.9.030 | Locknut                | 1   |
| 25               | 84.0002.1.099 | M6 Washer              | 1   |
| 26               | 84.0002.0.992 | M6x25 Butt Hd Screw    | 1   |
| 27               | 84.0002.1.028 | M6 Spring Washer       | 1   |
| 28               | 84.0002.8.210 | Rod End                | 1   |
| 29               | 84.0002.1.093 | M8 Plain Washer        | 1   |
| 30               | 84.0002.1.058 | M8 Nut                 | 2   |
| 31               | 84.0003.2.040 | Flow Control           | 2   |
| 32               | 84.0002.8.192 | Cylinder               | 1   |
| 33               |               | M4x6 Butt Hd Screw     | 1   |
| 34               | 84.0003.2.095 | M5-4mm Elbow Adaptor   | 1   |
| 35               | 84.0003.0.620 | Drive Cylinder Stud    | 1   |
| 36               | 84.0005.9.110 | Cover Stud             | 1   |
| 37               | 84.0005.9.023 | Jig Drive Base Plate   | 1   |
| 38               | 84.0002.0.807 | M5x10 Csk Screw        | 1   |
| 39               | 84.0005.7.055 | Drive Cover Guard      | 1   |
| 40               | 84.0004.6.525 | Thumb Nut, 8mm         | 2   |



# JIG DRIVE/JIG EJECT/SNUBBER



## JIG DRIVE/JIG EJECT/SNUBBER




| DET       | PART NUMBER   | DESCRIPTION         | QTY |
|-----------|---------------|---------------------|-----|
| JIG EJECT |               |                     |     |
| 41        | 84.0004.6.540 | Nylon Nose          | 1   |
| 42        | 84.0005.9.010 | Jig Eject Brkt      | 1   |
| 43        | 84.0002.0.984 | M5x16 Butt Hd Screw | 2   |
| 44        | 84.0002.1.098 | M5 Plain Washer     | 2   |
| 45        | 84.0004.6.950 | Jig Eject Cylinder  | 1   |
| 46        | 84.0003.2.045 | Flow Control        | 1   |
| SNUBBER   |               |                     |     |
| 47        | 84.0004.6.765 | Shock Absorber      |     |
| 48        | 84.0005.7.025 | Snubber Bkt         |     |
| 49        | 84.0005.7.030 | Nylon Damper Block  |     |
| 50        | 84.0002.0.984 | M5x16 Butt Hd Screw |     |
| 51        | 84.0002.1.098 | M5 Plain Washer     |     |
| 52        | 84.0005.7.122 | Rear Blower         |     |

*Not Illustrated:*

|               |                        |   |
|---------------|------------------------|---|
| 84.0005.9.140 | Jigh Drive Regulator   | 1 |
| 84.0006.0.325 | 4mm In Line Restrictor | 1 |

# PRESSER FOOT/JIG FLAP/AMPLIFIER






## PRESSER FOOT/JIG FLAP/AMPLIFIER

| DET                     | PART NUMBER   | DESCRIPTION               | QTY |
|-------------------------|---------------|---------------------------|-----|
| <b>PRESSER FOOT</b>     |               |                           |     |
| 1                       | 84.0002.0.840 | M3x5 Cap Hd Screw         | 1   |
| 2                       | 84.0005.7.060 | Photocell Mtg Bkt         | 1   |
| 3                       | 84.0003.0.715 | Fibre Optic Head          | 1   |
| 4                       | 84.0002.5.550 | Presser Foot 3/16"        | 1   |
| S                       | 84.0002.5.540 | Presser Foot 1/8"         | 1   |
| S                       | 84.0002.5.560 | Presser Foot 1/4"         | 1   |
| 5                       | 84.0005.7.120 | Foot Blower               | 1   |
| 6                       | 84.0002.1.026 | Finger Guard              | 1   |
| 7                       |               | Plain Washer              | 1   |
| 8                       | 08.7000.6.012 | Slot Hd Screw             | 1   |
| S=Special               |               |                           |     |
| <b>JIG FLAP</b>         |               |                           |     |
| 9                       | 84.0004.0.163 | Throat Plate Locating Pin | 1   |
| 10                      | 84.0005.9.040 | Jig Flap Bracket          | 1   |
| S                       | 84.0005.9.005 | Throat Plate, 1/8"        | 1   |
| 11                      | 84.0005.9.006 | Throat Plate, 3/16"       | 1   |
| S                       | 84.0005.9.007 | Throat Plate, 1/4"        | 1   |
| 12                      | 84.0005.7.130 | Throat Plate Screw        | 4   |
| 13                      | 84.0002.0.798 | M3x6 Csk Screw            | 1   |
|                         |               |                           |     |
| 15                      | M3x16         | Hex Hd Screw              | 1   |
| 16                      | 84.0002.1.085 | M3 Nut                    | 3   |
| 17                      | 84.0002.1.091 | M3 Plain Washer           | 2   |
| 18                      | 84.0004.6.840 | M2.5x5 Pan Hd Screw       | 2   |
| 19                      | 84.0004.6.540 | Nylon Nose                | 1   |
| 20                      | 84.0002.1.025 | M3 Spring Washer          | 2   |
| 21                      | 84.0002.0.841 | M3x8 Cap Hd Screw         | 2   |
| 22                      | 84.0003.2.045 | Flow Control              | 1   |
| 23                      | 84.0004.6.745 | Jig Flap Cylinder         | 1   |
| 24                      | 84.0004.6.755 | Jig Flap Cylinder Bracket | 1   |
| 25                      | 84.0004.6.750 | Jig Flap Spring           | 1   |
| 26                      | 84.0005.7.010 | Jig Eject Slide Plate     | 1   |
| 27                      | 84.0002.0.799 | M3x10 Csk Screw           | 2   |
| 28                      | 84.0005.9.050 | Jig Flap Cover Plate      | 1   |
| S=Special               |               |                           |     |
| <b>AMPLIFIER</b>        |               |                           |     |
| 29                      |               | Screw                     | 2   |
| 30                      | 12.0010.4.328 | Sensor Optic              | 1   |
| 31                      | 84.0005.7.059 | Spacer                    | 1   |
| <i>Not Illustrated:</i> |               |                           |     |
|                         | 84.0006.0.325 | 4mm In Line Restrictor    | 2   |


# TURN ARM



## TURN ARM


| DET | PART NUMBER   | DESCRIPTION             | QTY |
|-----|---------------|-------------------------|-----|
| 1   | 84.0003.1.000 | Turn Unit               | 1   |
| 2   | 84.0002.0.868 | M6x30 Cap Hd Screw      | 2   |
| 3   | 84.0003.2.040 | Flow Control            | 2   |
| 4   | 84.0002.0.853 | M4x35 Cap Hd Screw      | 1   |
| 5   | 84.0002.1.092 | M4 Plain Washer         | 2   |
| 6   | 84.0006.0.326 | "Y" Connector, 4mm      | 2   |
| 7   | 84.0005.9.011 | Turn Support Bkt        | 1   |
| 8   | 84.0005.9.019 | Piston Rod End Clevis   | 1   |
| 9   | 84.0005.9.013 | Knife Lever             | 1   |
| 10  | 84.0002.0.857 | M5x16 Cap Hd Screw      | 1   |
| 11  | 84.0005.9.012 | Outrigger Turner        | 1   |
| 12  | 84.0002.0.855 | M4x30 Cap Hd Screw      | 1   |
| 13  | 84.0003.2.110 | Straight Connector, 4mm | 2   |
| 14  |               | M5x55 Cap Hd Screw      | 2   |
| 15  | 84.0004.6.840 | Turn Arm Cylinder Nose  | 1   |
| 16  | 84.0004.6.825 | Turn Arm Cylinder       | 1   |
| 17  | 84.0004.6.835 | Turn Arm Cylinder Clamp | 1   |
| 18  | 84.0002.1.098 | M5 Plain Washer         | 1   |
| 19  | 84.0002.0.878 | M5 Spring Nut           | 2   |
| 20  | 84.0002.1.087 | M5 Nut                  | 2   |
| 21  | 84.0002.0.878 | M4x10 Cap Hd Screw      | 2   |
| 22  |               | Pipe Clamp              | 2   |
| 23  | 84.0004.6.695 | Turn Arm                | 1   |
| 24  | 84.0002.1.087 | M5 Nut                  | 1   |
| 25  | 84.0003.2.100 | 90° Elbow Adaptor       | 2   |
| 26  | 84.0005.9.018 | Knife Cylinder          | 1   |
| 27  |               | 15/64"x28x12 Screw      | 2   |
| 28  |               | M6x20 Cap Hd Screw      | 2   |
| 29  |               | M6x12 Btt Hd Screw      | 2   |
| 30  | 84.0005.9.017 | Clevis & Pin Kit        | 1   |
| 31  | 84.0002.1.088 | M6 Full Nut             | 2   |
| 32  | 84.0002.1.099 | M6 Plain Washer         | 2   |

## HEAD AND SYNCHRONIZER



| DET | PART NUMBER   | DESCRIPTION           | QTY |
|-----|---------------|-----------------------|-----|
| 1   | 12.0010.4.185 | EFKA Synchroniser     | 1   |
| 2   | 84.0005.7.035 | Synch. Stabiliser Arm | 1   |
| 3   | 84.0005.7.020 | Synch. Spigot         | 1   |
| 4   | 84.0005.7.036 | Holder                | 1   |
| 5   | 84.0005.9.096 | Sewing Head           | 1   |
| 6   | 84.0005.7.076 | Dense Adjusting Rod   | 1   |
| 7   | 84.0005.9.170 | Brush Mtg Brkt        | 1   |
| 8   | 84.0005.9.175 | Extension Bkt         | 1   |
| 9   | 84.0005.9.502 | Anti-static Brush     | 1   |
| 10  | 84.0002.0.856 | M5x12 Cap Hd Screw    | 1   |
| 11  | 84.0002.1.098 | M5 Plain Washer       | 1   |
| 12  | 84.0002.1.091 | M3 Plain Washer       | 4   |
| 13  | 84.0002.0.975 | M3x8 Butt Hd Screw    | 4   |
| 14  | 84.0002.1.092 | M3 Nut                | 4   |

# KNIFE MECHANISM



| DET | PART NUMBER   | DESCRIPTION              | QTY |
|-----|---------------|--------------------------|-----|
| 1   | 84.0005.9.174 | M2.5x6 Countersunk Screw | 2   |
| 2   | 84.0005.9.172 | Clamp Plate              | 1   |
| 3   | 84.0005.9.173 | 16mm Knife               | 1   |
| 4   | 84.0005.9.161 | 9mm Knife                | 1   |
| 5   | 84.0005.9.171 | Adapter                  | 1   |
| 6   | 08.6000.4.008 | Screw                    | 1   |
| 7   | 84.0005.9.166 | Slide Block              | 1   |
| 8   | 84.0005.9.685 | Clamp Screw              | 1   |
| 9   | 84.0005.9.166 | Adjustable Holder Bkt.   | 1   |
| 10  | 08.6012.1.008 | Slide Clamp Screw        | 1   |
| 11  | 08.6850.4.000 | Washer                   | 1   |

| 3/16"         | 1/4" | 1/8" |               |             |
|---------------|------|------|---------------|-------------|
|               |      | DET  | PART NUMBER   | DESCRIPTION |
| See page 3-15 |      | 1    | 08.6012.1.008 | Screw 2 PCS |
|               |      | 2    | 84.0005.9.167 | Plate       |
|               |      | 3,4  | 84.0003.0.310 | Knife       |
|               |      | 5    | 84.0005.9.165 | Holder      |



**INDEX**

| PART NUMBER   | PAGE | DET | QTY | PART NUMBER   | PAGE | DET | QTY | PART NUMBER   | PAGE | DET | QTY |
|---------------|------|-----|-----|---------------|------|-----|-----|---------------|------|-----|-----|
| 06.8400.1.005 | 3-3  | 32  | 1   | 84.0002.0.982 | 3-3  | 35  | 6   | 84.0002.5.550 | 3-11 | 4   | 1   |
| 06.8400.1.011 | 3-3  | 32  | 1   | 84.0002.0.984 | 3-7  | 7   | 4   | 84.0002.5.560 | 3-11 | S   | 1   |
| 08.6000.4.008 | 3-15 | 6   | 1   | 84.0002.0.984 | 3-9  | 43  | 2   | 84.0002.8.192 | 3-7  | 32  | 1   |
| 08.6000.5.012 | 3-5  | 68  | 1   | 84.0002.0.984 | 3-9  | 50  | 0   | 84.0002.8.200 | 3-7  | 9   | 2   |
| 08.6012.1.008 | 3-15 | 10  | 1   | 84.0002.0.992 | 3-7  | 26  | 1   | 84.0002.8.210 | 3-7  | 28  | 1   |
| 08.6012.1.008 | 3-15 | 1   | 0   | 84.0002.1.025 | 3-11 | 20  | 2   | 84.0002.9.010 | 3-7  | 16  | 1   |
| 08.6850.4.000 | 3-15 | 11  | 1   | 84.0002.1.026 | 3-3  | 23  | 2   | 84.0002.9.020 | 3-7  | 23  | 1   |
| 08.6850.5.000 | 3-5  | 69  | 1   | 84.0002.1.026 | 3-7  | 13  | 1   | 84.0002.9.030 | 3-7  | 24  | 1   |
| 08.7000.6.012 | 3-11 | 8   | 1   | 84.0002.1.026 | 3-11 | 6   | 1   | 84.0002.9.060 | 3-7  | 8   | 1   |
| 12.0008.4.583 | 3-5  | 43  | 1   | 84.0002.1.028 | 3-5  | 56  | 2   | 84.0002.9.070 | 3-7  | 21  | 1   |
| 12.0008.4.584 | 3-5  | 44  | 1   | 84.0002.1.028 | 3-7  | 27  | 1   | 84.0002.9.125 | 3-7  | 17  | 1   |
| 12.0010.4.098 | 3-5  | 43  | 1   | 84.0002.1.058 | 3-3  | 38  | 3   | 84.0002.9.126 | 3-7  | 22  | 1   |
| 12.0010.4.098 | 3-5  | 44  | 1   | 84.0002.1.058 | 3-7  | 30  | 2   | 84.0003.0.310 | 3-15 | 3,4 | 0   |
| 12.0010.4.099 | 3-3  | 40  | 1   | 84.0002.1.068 | 3-3  | 37  | 3   | 84.0003.0.511 | 3-7  | 3   | 1   |
| 12.0010.4.101 | 3-3  | 1   | 1   | 84.0002.1.085 | 3-3  | 13  | 2   | 84.0003.0.620 | 3-7  | 35  | 1   |
| 12.0010.4.102 | 3-5  | 45  | 1   | 84.0002.1.085 | 3-3  | 24  | 2   | 84.0003.0.715 | 3-11 | 3   | 1   |
| 12.0010.4.185 | 3-14 | 1   | 1   | 84.0002.1.085 | 3-5  | 62  | 1   | 84.0003.1.000 | 3-13 | 1   | 1   |
| 12.0010.4.325 | 3-5  | 60  | 1   | 84.0002.1.085 | 3-11 | 16  | 3   | 84.0003.2.015 | 3-3  | 28  | 1   |
| 12.0010.4.327 | 3-3  | 32  | 1   | 84.0002.1.086 | 3-5  | 62  | 1   | 84.0003.2.040 | 3-7  | 31  | 2   |
| 12.0010.4.328 | 3-11 | 30  | 1   | 84.0002.1.086 | 3-5  | 64  | 4   | 84.0003.2.040 | 3-13 | 3   | 2   |
| 84.0002.0.719 | 3-5  | 52  | 1   | 84.0002.1.087 | 3-7  | 5   | 1   | 84.0003.2.045 | 3-9  | 46  | 1   |
| 84.0002.0.727 | 3-3  | 2   | 1   | 84.0002.1.087 | 3-13 | 20  | 2   | 84.0003.2.045 | 3-11 | 22  | 1   |
| 84.0002.0.798 | 3-11 | 13  | 1   | 84.0002.1.087 | 3-13 | 24  | 1   | 84.0003.2.095 | 3-3  | 12  | 1   |
| 84.0002.0.799 | 3-11 | 27  | 2   | 84.0002.1.088 | 3-5  | 55  | 2   | 84.0003.2.095 | 3-7  | 34  | 1   |
| 84.0002.0.807 | 3-7  | 38  | 1   | 84.0002.1.088 | 3-7  | 4   | 1   | 84.0003.2.100 | 3-3  | 2   | 1   |
| 84.0002.0.840 | 3-11 | 1   | 1   | 84.0002.1.088 | 3-13 | 31  | 2   | 84.0003.2.100 | 3-13 | 25  | 2   |
| 84.0002.0.841 | 3-11 | 21  | 2   | 84.0002.1.091 | 3-11 | 17  | 2   | 84.0003.2.105 | 3-3  | 18  | 1   |
| 84.0002.0.842 | 3-7  | 20  | 2   | 84.0002.1.091 | 3-14 | 12  | 4   | 84.0003.2.105 | 3-5  | 47  | 1   |
| 84.0002.0.843 | 3-5  | 62  | 1   | 84.0002.1.092 | 3-3  | 22  | 2   | 84.0003.2.107 | 3-3  | 25  | 1   |
| 84.0002.0.845 | 3-3  | 16  | 1   | 84.0002.1.092 | 3-5  | 62  | 1   | 84.0003.2.108 | 3-3  | 30  | 1   |
| 84.0002.0.851 | 3-5  | 59  | 4   | 84.0002.1.092 | 3-13 | 5   | 2   | 84.0003.2.110 | 3-3  | 10  | 1   |
| 84.0002.0.851 | 3-5  | 63  | 4   | 84.0002.1.092 | 3-14 | 14  | 4   | 84.0003.2.110 | 3-13 | 13  | 2   |
| 84.0002.0.852 | 3-3  | 21  | 2   | 84.0002.1.093 | 3-3  | 38  | 3   | 84.0003.2.120 | 3-5  | 50  | 1   |
| 84.0002.0.853 | 3-13 | 4   | 1   | 84.0002.1.093 | 3-7  | 29  | 1   | 84.0003.2.150 | 3-3  | 15  | 1   |
| 84.0002.0.855 | 3-7  | 12  | 1   | 84.0002.1.098 | 3-7  | 6   | 1   | 84.0003.2.155 | 3-3  | 31  | 1   |
| 84.0002.0.855 | 3-13 | 12  | 1   | 84.0002.1.098 | 3-9  | 44  | 2   | 84.0004.0.163 | 3-11 | 9   | 1   |
| 84.0002.0.856 | 3-14 | 10  | 1   | 84.0002.1.098 | 3-9  | 51  | 0   | 84.0004.6.525 | 3-7  | 40  | 2   |
| 84.0002.0.857 | 3-13 | 10  | 1   | 84.0002.1.098 | 3-13 | 18  | 1   | 84.0004.6.530 | 3-7  | 11  | 1   |
| 84.0002.0.868 | 3-13 | 2   | 2   | 84.0002.1.098 | 3-14 | 11  | 1   | 84.0004.6.535 | 3-7  | 10  | 1   |
| 84.0002.0.871 | 3-5  | 53  | 2   | 84.0002.1.099 | 3-5  | 54  | 2   | 84.0004.6.540 | 3-9  | 41  | 1   |
| 84.0002.0.878 | 3-5  | 62  | 1   | 84.0002.1.099 | 3-7  | 25  | 1   | 84.0004.6.540 | 3-11 | 19  | 1   |
| 84.0002.0.878 | 3-13 | 19  | 2   | 84.0002.1.099 | 3-13 | 32  | 2   | 84.0004.6.565 | 3-5  | 58  | 1   |
| 84.0002.0.878 | 3-13 | 21  | 2   | 84.0002.5.280 | 3-7  | 15  | 1   | 84.0004.6.695 | 3-13 | 23  | 1   |
| 84.0002.0.922 | 3-7  | 14  | 2   | 84.0002.5.290 | 3-7  | 18  | 1   | 84.0004.6.745 | 3-11 | 23  | 1   |
| 84.0002.0.948 | 3-5  | 41  | 4   | 84.0002.5.490 | 3-5  | 46  | 3   | 84.0004.6.746 | 3-3  | 11  | 1   |
| 84.0002.0.975 | 3-14 | 13  | 4   | 84.0002.5.540 | 3-11 | S   | 1   | 84.0004.6.750 | 3-11 | 25  | 1   |

## INDEX

| PART NUMBER   | PAGE | DET | QTY | PART NUMBER   | PAGE | DET | QTY | PART NUMBER | PAGE | DET | QTY |
|---------------|------|-----|-----|---------------|------|-----|-----|-------------|------|-----|-----|
| 84.0004.6.755 | 3-11 | 24  | 1   | 84.0005.9.005 | 3-11 | S   | 1   |             |      |     |     |
| 84.0004.6.765 | 3-9  | 47  | 0   | 84.0005.9.006 | 3-11 | 11  | 1   |             |      |     |     |
| 84.0004.6.795 | 3-3  | 7   | 1   | 84.0005.9.007 | 3-11 | S   | 1   |             |      |     |     |
| 84.0004.6.806 | 3-5  | 48  | 1   | 84.0005.9.010 | 3-9  | 42  | 1   |             |      |     |     |
| 84.0004.6.825 | 3-13 | 16  | 1   | 84.0005.9.011 | 3-13 | 7   | 1   |             |      |     |     |
| 84.0004.6.835 | 3-13 | 17  | 1   | 84.0005.9.012 | 3-13 | 11  | 1   |             |      |     |     |
| 84.0004.6.840 | 3-11 | 18  | 2   | 84.0005.9.013 | 3-13 | 9   | 1   |             |      |     |     |
| 84.0004.6.840 | 3-13 | 15  | 1   | 84.0005.9.017 | 3-13 | 30  | 1   |             |      |     |     |
| 84.0004.6.847 | 3-3  | 20  | 10  | 84.0005.9.018 | 3-13 | 26  | 1   |             |      |     |     |
| 84.0004.6.865 | 3-3  | 2   | 1   | 84.0005.9.019 | 3-13 | 8   | 1   |             |      |     |     |
| 84.0004.6.920 | 3-7  | 19  | 1   | 84.0005.9.023 | 3-7  | 37  | 1   |             |      |     |     |
| 84.0004.6.935 | 3-7  | 2   | 1   | 84.0005.9.040 | 3-11 | 10  | 1   |             |      |     |     |
| 84.0004.6.940 | 3-3  | 27  | 2   | 84.0005.9.050 | 3-11 | 28  | 1   |             |      |     |     |
| 84.0004.6.950 | 3-9  | 45  | 1   | 84.0005.9.096 | 3-14 | 5   | 1   |             |      |     |     |
| 84.0004.7.150 | 3-3  | 39  | 1   | 84.0005.9.110 | 3-7  | 36  | 1   |             |      |     |     |
| 84.0004.8.045 | 3-3  | 29  | 1   | 84.0005.9.140 | 3-9  | 0   | 1   |             |      |     |     |
| 84.0004.8.085 | 3-7  | 1   | 1   | 84.0005.9.161 | 3-15 | 4   | 1   |             |      |     |     |
| 84.0004.8.455 | 3-5  | 42  | 1   | 84.0005.9.165 | 3-15 | 5   | 0   |             |      |     |     |
| 84.0004.8.994 | 3-5  | 65  | 1   | 84.0005.9.166 | 3-15 | 7   | 1   |             |      |     |     |
| 84.0004.8.995 | 3-5  | 66  | 1   | 84.0005.9.166 | 3-15 | 9   | 1   |             |      |     |     |
| 84.0004.8.996 | 3-5  | 66  | 3   | 84.0005.9.167 | 3-15 | 2   | 0   |             |      |     |     |
| 84.0005.7.010 | 3-11 | 26  | 1   | 84.0005.9.170 | 3-14 | 7   | 1   |             |      |     |     |
| 84.0005.7.020 | 3-14 | 3   | 1   | 84.0005.9.171 | 3-15 | 5   | 1   |             |      |     |     |
| 84.0005.7.025 | 3-9  | 48  | 0   | 84.0005.9.172 | 3-15 | 2   | 1   |             |      |     |     |
| 84.0005.7.030 | 3-9  | 49  | 0   | 84.0005.9.173 | 3-15 | 3   | 1   |             |      |     |     |
| 84.0005.7.035 | 3-14 | 2   | 1   | 84.0005.9.174 | 3-15 | 1   | 2   |             |      |     |     |
| 84.0005.7.036 | 3-14 | 4   | 1   | 84.0005.9.175 | 3-14 | 8   | 1   |             |      |     |     |
| 84.0005.7.055 | 3-7  | 39  | 1   | 84.0005.9.502 | 3-14 | 9   | 1   |             |      |     |     |
| 84.0005.7.059 | 3-11 | 31  | 1   | 84.0005.9.683 | 3-5  | 70  | 1   |             |      |     |     |
| 84.0005.7.060 | 3-11 | 2   | 1   | 84.0005.9.684 | 3-5  | 67  | 1   |             |      |     |     |
| 84.0005.7.076 | 3-14 | 6   | 1   | 84.0005.9.685 | 3-15 | 8   | 1   |             |      |     |     |
| 84.0005.7.095 | 3-3  | 9   | 1   | 84.0006.0.325 | 3-9  | 0   | 1   |             |      |     |     |
| 84.0005.7.110 | 3-3  | 5   | 1   | 84.0006.0.325 | 3-11 | 0   | 2   |             |      |     |     |
| 84.0005.7.115 | 3-3  | 34  | 1   | 84.0006.0.326 | 3-13 | 6   | 2   |             |      |     |     |
| 84.0005.7.116 | 3-3  | 34  | 1   | 84.0006.0.989 | 3-3  | 14  | 1   |             |      |     |     |
| 84.0005.7.120 | 3-11 | 5   | 1   | 84.0010.7.350 | 3-5  | 51  | 1   |             |      |     |     |
| 84.0005.7.122 | 3-9  | 52  | 0   |               |      |     |     |             |      |     |     |
| 84.0005.7.125 | 3-3  | 19  | 1   |               |      |     |     |             |      |     |     |
| 84.0005.7.130 | 3-11 | 12  | 4   |               |      |     |     |             |      |     |     |
| 84.0005.7.146 | 3-3  | 36  | 1   |               |      |     |     |             |      |     |     |
| 84.0005.8.625 | 3-3  | 3   | 1   |               |      |     |     |             |      |     |     |
| 84.0005.8.627 | 3-3  | 4   | 5   |               |      |     |     |             |      |     |     |
| 84.0005.8.680 | 3-3  | 32  | 1   |               |      |     |     |             |      |     |     |
| 84.0005.8.680 | 3-5  | 0   | 3   |               |      |     |     |             |      |     |     |
| 84.0005.8.682 | 3-5  | 0   | 3   |               |      |     |     |             |      |     |     |
| 84.0005.8.684 | 3-5  | 0   | 1   |               |      |     |     |             |      |     |     |